

# M2M Modbus RS485 IO<sup>®</sup> modem

## Installation Manual

v1.2



Rev: 1.2  
2018-07-17

## Document specifications

This document was made by the *WM Rendszerház Kft.* for **M2M Modem Plus®** and **M2M Modem Plus IO®** product family members.

The document contains the description of the technical data, operation and construction of the devices.

<b>Document category:</b>	Installation Manual
<b>Product:</b>	Modbus RS485 IO
<b>Made by:</b>	Tóth Csaba, WM Systems LLC.
<b>Contact:</b>	Email: <a href="mailto:csaba.toth@m2mserver.com">csaba.toth@m2mserver.com</a>
<b>Validated by:</b>	Krizsán Mihály
<b>Document version:</b>	REV 1.20
<b>Pages:</b>	20
<b>Hardware version:</b>	REV 1.1.0
<b>Document status:</b>	Final
<b>Class:</b>	Public
<b>Made at:</b>	8th of December, 2016.
<b>Last changes:</b>	17th of July, 2018
<b>Date of authorization:</b>	17th of July, 2018

# Table of Contents

<b>1. MODEM OPERATION</b> .....	<b>4</b>
1.1 Modem versions .....	4
1.2 Main features .....	5
1.3 Port connectors .....	5
<b>2. INSTALLATION AND CONFIGURATION</b> .....	<b>7</b>
2.1 installation .....	7
2.2 Configuration .....	8
2.3 Checking the configuration and operation .....	10
2.4 Starting and the usage of the modem .....	10
2.5 LED signals .....	11
<b>3. IMPORTANT NOTES</b> .....	<b>12</b>
<b>4. SUPPORT</b> .....	<b>15</b>
<b>5. LEGAL NOTICE</b> .....	<b>15</b>

# Chapter 1. Modem Operation

## 1.1 Introduction

The modem can be ordered with several software and firmware variations according to the different purpose of usage.

Before configure the modem, check the available features in the next table – which contains the most important properties of the modes.

Data communication / Connection	IO (4- or more* inputs, 2 outputs) +RS232 (DB9) or RS485
Transparent communication	GPRS data sending
Automatic mobile network reconnection	YES
Readout of Modbus registers (Function Code 3)	YES
PLC / Data concentrator connect.	YES
Modbus Gateway (incoming Modbus TCP message from GPRS and forwarded to serial port in Modbus RTU format for a PLC)	YES
Pulse signal counting	YES
Voltage/Contact input	YES
Relay output switch	OPTIONAL
Modbus TCP client connection possibility (industrial standard)	YES
Modbus TCP server connection (Scada, AVReporter)	OPTIONAL
Sabotage sensing	OPTIONAL
2MB flash memory for storage of programs, data	OPTIONAL, with Ftp usage
Watchdog, monitoring, log	YES
Firmware updates (ftp server)	YES
Configuration with software	RS232 or RS485

The modem is also capable of connecting to a data concentrator. In this mode, we offer the M2M IO/RS485 CONCENTRATOR to connect, which provides you further 32 digital inputs for the connection. The number of the inputs can be raised by connecting further data concentrators up to hundreds of input lines.


## 1.2 Product Overview

- Power Supply: 12V 1A (10-32V DC, 8-24V AC), battery (12V or 16V)
- Current: stand-by: 20mA @ 12V, max.: 150mA
- Gemalto® MC55i-W GSM/GPRS modem (850/900/1800/1900MHz), SMA (50 Ohm) antenna connection
- Input high signal level: 5-24V, low signal level: 0-1V
- Input operation mode: 12V Voltage or Pulse (max. 12V), Contact (sensing short/wire cut)

- Current in active status: 5-7 mA, switchable voltage: 2A 120VAC, 1A 24VDC
- C-rail mountable, industrial aluminum case, IP51 protection
- Operation temperature: -40°C..+85°C, storage temperature: -40°C..+85°C

### **1.3 Port connections**

The modem front-face lag and bottom-side lag description can be found here for the available versions.



- 1 - SMA antenna connector (50 Ohm)**
- 2 - RS485 port connector**  
(in case of RS232 version cannot be used!)
- 3 - RS232 (Dsub9) serial port (DCE)**
- 4 - GSM/GPRS status LED**


- 5 - AC/DC power supply connector port (-/+)**
- 6 - Battery connection (-/+)**
- 7 - 4 earth independent input lines**  
(Input1..Input4 -/+)
- 8 - 2 relay output lines (Out1 -/+, Out2 -/+)**
- 9 - Custom LED (optional, programmable)**

## Chapter 2. Installation and Configuration

### 2.1 Installation


Let's follow the hints in sequence for the successful installation and configuration of the modem:

1. Unplug the power cable (**5** or **6**) from the modem – if it was connected to the power – then the **Status LED** will not light further.
2. Remove the two screws from front-plate and slide the PCB from the antenna connector side, while the SIM-card holder will appear.
3. Push the SIM-holder fixation lag to the **OPEN** position, open up and insert the SIM card in the right direction into the SIM-holder. Then close it and push it back to the **LOCK** position.
4. When the modem will connect on the RS232 interface, then remove the RS485 additional expansion PCB from the mainboard. (When you will use the modem through RS485 then not necessary to change the boards).
5. Assemble the mainboard into the case and fix the front-plate with the screws.
6. Connect and mount a GSM/GPRS antenna (50 Ohm) to the SMA connector (**1**).
7. Connect a RS232 serial cable to the DB9 (**3**) port, and the PC to the other side of cable (when the PC has only USB port, you also have to use a RS232-USB converter and its driver must be installed to the PC).
8. Download the **Modem Configurator** from the product webpage from our site here: <http://www.m2mserver.com/en/product/m2m-modbus-rs485-io/>
9. Uncompress the downloaded file to your PC.



### 2.2 Configuration

1. Execute the **ModemCfg2.exe** file on a *Windows* system.
2. Choose the proper serial port number at the **COM** field (drop-down the list and choose). Then push the **Connect** button.
3. Turn on the modem (give the power supply to the **5 6** (or **6** if battery will be used)).
4. Wait until you will receive the **Modem Connection OK** message (ca. 30-40 seconds) in the framed message box.



5. Push the **Read** button and wait until the **Modem Connection OK** message will appear again – wait for another 30-40 seconds.
6. Modify the settings (for details, see above), then push the **Write** button and wait for the **Modem Connection OK** message.
7. When you have finished, push the **Disconnect** button and disconnect the RS232/RS485 cable (**2** or **3**).
8. Restart the modem – by unplug and connect the power supply. Then the modem will operating regarding the new configuration settings.
9. In case of error/fault: You will found the CommLine.txt file in the program directory. In case of the support line, you have to send this log file.

### **Configurable Parameter settings:**

#### **GPRS settings:**

- **APN:** APN network name by the mobile operator, for using the internet zone
- **UserName:** given by the mobile operator, for using the internet zone
- **Password:** given by the mobile operator, for using the internet zone

#### **Server settings:**

- **Destination IP:** Server IP where you will send the data. (The IP must be accessible on the mobile network (format as 123.123.123.123))
- **Destination Port:** Server access port number where the data will be sent

**MCC+MNC:** GSM service code (5 digit number, ask your mobile operator)



**Serial Values** (serial port parameters) – in sequence with comma separated (without space character), e.g.: 9600,8N1,NONE


- **Speed:** 1200 / 2400 / 4800 / 9600 / 19200 / 38400 /115200
- **Data bits:** 7 / 8, **Parity:** **N** (none) / **E** (even) / **O** (odd)
- **Stop bits:** 1 / 2, **Hardware control:** NONE / HW

### 2.3 *Checking the configuration and operation*

- **GPRS signal strength** by the **Signal Strength Current Cell** button (value at the **Local Cell**). It must be between 30 and 85. When the value is different, then change the antenna position or its location. When you get 0 or -99 value it means a fault or no antenna attached.
- **Mobile Internet connection** test to the GPRS network with the **GPRS CHK** button.
- **Server IP** availability with the **PING** (server IP), the **Period** (in seconds), **Err** (ping retry).

### 2.4 *Starting and usage of the modem*


1. The RS232 and RS485 ports cannot be used in the same time! You have to choose the RS232 OR the RS485 connection.
2. When the Modem Plus RS485 device will be used with RS232 serial interface, first of all the internal RS485 expansion board must be removed!





### In case of IO versions:

3. Turn off the device then connect the wires of the input line(s) (**7 - IN1..IN4**). and the output wire(s) (**8 - OUT1..OUT2**) – to the terminal blocks. **In case of using voltage input line(s), take care about the polarity when wiring!**
4. Setup the input operation mode at the input lines – see figure at nr. **10** (jumper in upper position: 12V Voltage polarity, or max. 12V pulse signal (for pulse counting), in low position: Contact (short/wire cut detection)



### RS232/RS485 wiring:

5. Connect the RS232 cable (**3**) or the RS485 (**2**) connector, due to the terminal block (use only one of them in the same time!)

### Turning on the modem:

6. Turn on the modem by adding the power supply at the AC/DC (**5**) port or/and add an external battery (**6**). The battery can be used together with the PSU as well – as a spare supply (in this case the battery will be charged from the power source).
7. When you will turn on the modem, the internal LED signals will be operating according the wiring. IO LEDs (**11**) and power LED (**12**) will sign the operation.
8. Check the **GSM/GPRS** LED signals (**4**) and wait while the modem connects to the GPRS network. Use the device according to the uploaded software.

## **2.6 LED signals**

The modem has 7pcs internal and 3 pcs external LEDs.

### Internal LEDs:

- 4 input LEDs (11) – IO port
- 2 output LEDs (11) – IO port
- 1 power LED (12)

#### External LEDs:

- GPRS LED (4) – for signing the modem connection and the data communication
- Programmable LED (9) – free to use, programmable
- it has one another free to use and programmable LED for further developments and usage.

When giving the power supply to the modem, the GPRS LED signs the system initialization and starting, and the modem operation regarding the following signals:

#### **GPRS LED (4)**

<b>Not lights</b>	the modem is turned off or in stand-by operation mode
<b>Blinks in every 0.5 second</b>	no SIM-card/ bad PIN code / searching the GPRS network / connection in progress
<b>1 short blinking in every 3 seconds</b>	connection to the GPRS network was successful / GPRS data connection is active
<b>Blinking in every 0.5 seconds</b>	GPRS data transmitting/receiving, sending data
<b>Lights</b>	initiating the data connection/disconnection , transmitting parameters

## **Chapter 3. Important notes**

### **Software versions**

Our company have developed more than a dozen of the M2M Modbus RS485 IO applications for the customer needs and different purposes, during the years. Therefore, the current a default factory software version can be uploaded by us with the proper communication protocol software by the Customer requirements. The modems are shipped with the appropriate software version, according to your needs.

When ordering, please clarify that for which tasks will be used the modem and what kind of data connection and which registers must be readout or will be received by the modem. Furthermore you have to define the data sending requirements (as data sending interval or the transparent communication needs).

### **Using external communication antenna**

The GPRS data communication is only operating with the help of using an GSM/GPRS antenna – you may choose a 2 or 5 dBi gained one. The modem cannot communicate on the network without an antenna.

### **Using an external battery or accumulator**

Take care of the polarity when connect the battery wires!

You are allowed to use a 12V or 16V battery! The battery can be used as a spare power source or a standalone source (without the ACDC).

When you are using all the two sources, then the battery will be recharged from the ACDC.

### **Safe shutdown or restart of the modem**

Simply unplug the power connector of the nr. 5 and/or the nr. 6 power source(s). The modem will halted immediately.

When you would like to restart the modem, you may wait 5 seconds, then plug the power connector of the power source to the modem. Take care for the power wire polarity!

### **Cables, wiring**

You are allow to wiring ONLY on a turned off device!

## **Call center**

Our support needs the properly used software version nr. for the better identification, therefore you may give us further information to locate the project, aim, usage of the Modem Plus.

## Chapter 4. Using AT-commands with the modem

### Accessing the modem with AT commands

The AT command interface can be reached by a DATA call, e.g. for remote restarting of the device. For first you have to setup the call phone number and the ph. nr. sending and displaying must be active. You have to request the CSD data service from your mobile operator.

The AT-commands can be executed from a terminal application (as the Windows Hyperterminal, extraputty, etc.).

The Modem Plus-ban has an internal Gemalto MC55i-W module whereas, the AT command set of the module can be downloaded from our website, here:

[http://www.m2mserver.com/m2m-downloads/mc55i-w\\_atc\\_v01301a.pdf](http://www.m2mserver.com/m2m-downloads/mc55i-w_atc_v01301a.pdf)

### Checking the accessibility of the modem

You can ping the IP address which is using by the SIM card, therefore you can check the modem availability on the GPRS network.

Furthermore, you can ask us to provide a software version, where you can define an IP address for the modem for automatic ping by the device – as for continuous checking of the GPRS network connection.

The service has to be also required by the service provider of the SIM card!

The next AT command will help you:

**AT+CLIP=1**

**AT+CLIR= # 31 #**

(Sometimes the call can be initiated with the USSD code, when the device sends the ph. number, **if it were configured at the provider's system**)

### Calling the modem on GMS service

**\*31#SIMphonenumber**

The customer can call the Modem Plus to ask the modem software to handle the incoming call.

This CSD data service must be also granted by your mobile operator!

The further GSM service codes are described here:

<http://www.geckobeach.com/cellular/secrets/gsmcodes.php>

## **Accessing the memory/data**

### **ATD`phonenumber` or ATD\*31#`phonenumber`**

Then you will get an AT command interface, whereas you can query the flash storage content by the **AT#DIR** command.

You can download the files with the *Y modem* protocol and with the **AT#READY=filename** command. Then you have to allow receivment of the incoming file with the serial terminal application – to save the file to your PC.

## **SMS messages**

Some software versions are able to send or forward SMS text messages.

The related commands can be found in the Gemalto MC55i-W module AT command set description.

## **Email sending**

Some software versions are able to receive POP3 email messages and forward them.

The related commands can be found in the Gemalto MC55i-W module AT command set description.

## **Accessing the File system and handling files**

By using AT-commands, you can access the files and listing them, which are all located in the modem's non-volatile memory. You can move, delete, create or copy files by following the next hints.

This can be grateful when there are created files here on the modem and the data are continuously incoming to the modem device. There you may need to transfer or copy these files to a remote location (remote IP address) by the local ftp service, and after the transmission you will be attempting to delete the unnecessary files.

Certainly, you can automatize the executing of these commands by creating a script.

The next part will list the main important, basic file handling methods and modes, syntax.

## **Listing files, directory**

Command: **AT#DIR**

By answering the command, the files of the current directory will be listed with its length, date and name. Lastly, the free space of the memory will be also signed.



Example for response of the command:

```
----- 1 ewe ewe 3873 Jan 1 10:12 industrial.jpg
----- 1 ewe ewe 7868 Jan 1 10:12 indust-io.jpg
----- 1 ewe ewe 3197 Jan 1 10:12 industrial.htm
----- 1 ewe ewe 119 Jan 1 10:12 indust.cid
----- 1 ewe ewe 242 Jan 1 10:12 indust.ini
Free space: 1504768
OK
```

### **Reading a text file, displaying**

Command: **AT#TAIL=<file\_name>**

Example: *AT#TAIL=test.txt*

### **Reading an XMODEM text file, displaying**

The process of reading can be interrupted anytime with the Ctrl-X buttons.

Command: **AT#READ=<file\_name>**

Example: *AT#READ=test.txt*

### **Writing XMODEM file**

The XMODEM file can be written to the DTE by the following command. Then the Xmodem-1K protocol will be used for transmitting the file. After executing the command, the DTE starts the transmission of the Xmodem file to a remote distance. The process of reading can be interrupted anytime with the Ctrl-X buttons.

Command: **AT#WRITE=<file\_name>,<size>**

The packet size can be configured between 1K and 128 bytes, where the value of *size* parameter is in *byte* currency.

Example: *AT#WRITE=test.xmodem,128*

### **Deletion of a file**

Command: **AT#DEL=<file\_name>**

The filename can be max. 80 characters long.

Be very careful, when deleting files!

Example: *AT#DEL=test.txt*

## **Ping an IP address**

Command: **AT#PING=<server\_mnemonic>**

The **<server\_mnemonic>** parameter means a remote IP address, which you are attempting to access.

The ping command sequence waits 10 seconds between the steps. Response will be the OK message or a failure message.

## **Using an FTP client**

The device can connect to an ftp client (the usage requirement of the ftp service must be taken for ahead, because we have to upload the proper software for that). The ftp data port nr. is 20 and the control port nr. is 21. The ftp operates in passive mode only. After filling the necessary client-side settings, the temporary data on the modem will be accessible. The further aim of the data storage on the modem is a secondary data path for case of network outage.

### **FTP services:**

#### **Opening a new Ftp session**

When you would like to work with ftp, its necessary to open an ftp session for performing any further operation (e.g. before receiving or sending a file).

Command: **AT#FTPOPEN=<FTPServer>,<user-name>,<password>**

Parameters:

**<FTPServer>** the IP address of the ftp server IP címe, where you can use domain name also ( as [ftp.server.com](http://ftp.server.com) or similar).

**<username>** the registered username/account on the ftp server which is necessary to declare for the connection.

**<password>** the registered account's password on the ftp server which is necessary to declare for the connection

Example: *AT#FTPOPEN=192.168.1.1,user1,pwd1*

#### **Closing an Ftp session**

If you don't need the opened ftp session furthermore, you can close it by the next command.

Command: **AT#FTPCLOSE**

## ***Attention!***

***The following command are requiring an opened ftp session as a prerequisite!***

### **Listing a directory through Ftp**

You can check the current directory / position in the path on the remotely located server.

Command: **AT#FTPCWD**

### **Changing a directory on Ftp**

Here you can configure the workplace (directory) on the remote server.

Command: **AT#FTPCWD=<directory>**

The **<directory>** parameter defines a location path on the remote server.

Example: *AT#FTPCWD=/home/usr/bin*

### **Listing files with Ftp**

List the located files in a directory (at the remote server):

Command: **AT#FTPLST**

### **Downloading a file with Ftp**

Download file(s) by ftp, from the remote server.

Command: **AT#FTPREAD=<file\_name>**

The **<file\_name>** parameter defines the filename you are attempting to download.

Example: *AT#FTPREAD=file1.txt*

### **Sending/uploading a file with Ftp**

Upload file(s) by ftp, from the local modem to the remote server.

Command: **AT#FTPWRITE=<file\_name>**

The **<file\_name>** parameter defines the filename you are attempting to upload

Example: *AT#FTPWRITE=file2.txt*

### **Delete remote file(s) through Ftp**

When you don't need a file on the remote ftp server, you can delete it.

Command: **AT#FTPDEL=<file\_name>**

The **<file\_name>** parameter defines the filename you are attempting to delete.

### **Daily planned restart**

The daily normal restart of the modem is not programmed. When you would like to restart the modem every day you are allowed to use a schedulable or programmable connector switch.

### **Manual restart**

It is possible with executing the **AT#RESET** or the **AT#QUIT** command.

## Chapter 5. Support availability

Should you have any questions regarding the usage of the device, you can contact us in the following ways:

Email: [support@m2mserver.com](mailto:support@m2mserver.com)

Telephone: +36 20 333 1111

### ***5.1 Support help***

For identifying the device, please, use the sticker on the PCB, which contains important information to the support staff.

#### ***ATTENTION***

*The product sticker removal causes loss of the warranty!*

### ***5.2 Product support***

Click the following link to download the available product documentations and software:

**M2M Modbus RS485 IO:** <http://www.m2mserver.com/en/product/m2m-modbus-rs485-io/>

The documents and softwares related to the product are available at our website:

<http://www.m2mserver.com/en/support/>

Online product support can be used at here:

<http://www.m2mserver.com/en/support/>

## Chapter 6. Legal notice

©2018. WM Systems LLC.

The content of this documentation (all information, pictures, tests, descriptions, guides, logos) is under copyright protection. Copying, using, distributing and publishing it is only permitted with the consent of WM Systems LLC., with clear indication of the source.

The pictures in the user guide are only for illustration purposes.

WM Systems LLC. does not acknowledge or accept responsibility for any mistakes in the information contained in the user guide.

The published information in this document is subject to *change without notice*.

All data contained in the user guide is for information purposes only. For further information, please, contact our colleagues.

### **Warning**

Any errors occurring during the program update process may result in failure of the device.